

STANDARD OPERATING PROCEDURE

Prep & Sanding Metal Substrates

Sand to Paint

Sand to Prime

		Sand to Prime		Sand to Paint
Inspect	1	Inspect repair area for defects. Assure area is properly repaired & prepped. Return to body dept if necessary.	1	Inspect repair area for defects. Assure area is properly prepped & primed. Return to body/prep dept if necessary.
Clean	2	Clean repair area with solvent-borne degreaser, SCAT #6311 or Speedi SCAT #6321.	2	Clean repair area with solvent-borne degreaser, SCAT #6311 or Speedi SCAT #6321.
כ	3	Clean with waterborne degreaser, Aqua SCAT 2 #1394.	3	Clean with waterborne degreaser, Aqua SCAT 2 #1394.
	4	Sand repair area with 180-240 grit on palm sander.	4	Apply Low Spot Finder Guide Coat #9183 to surface. Block sand primed area with 320 grit (wet or dry) to eliminate orange peel.
Sand	5	Sand surrounding area with red scuff pad.	5	Apply Low Spot Finder Guide Coat #9183 again. Finish sanding repair area with 400-600 grit on palm sander.
			6	Dull shiny areas for blend with 800-1000 grit (wet or dry) or gray/green scuff pad & Scuff /Prep Paste #6338.
Clean	6	Blow off vehicle. Wipe repair area with Aqua SCAT 2 #1394.	7	Blow off vehicle/wash off paste. Wipe with Aqua SCAT 2 #1394.
Mask	7	Mask area to be primed.	8	Move vehicle into spray booth. Mask area to be painted.
Clean	8	Wipe repair area with Aqua SCAT 2 #1394.	9	Wipe with Aqua SCAT 2 #1394.
Prime	9	On Exposed Bare Metal: Tack off. Apply corrosion protection primer.	10	On Exposed Bare Metal: Tack off. Apply corrosion protection primer.
Prime	10	Tack off. Apply primer surfacer to repair area according to TDS using <i>Outside-in method</i> .		Application #1 #2 #3
		Go to column 2, Step 1.		
Topcoat			11	Apply sealer & topcoat per Transtar SOP 509. For blending, see SOP 513/4.

SUGGESTED MATERIAL FOR JOB

- Transtar Solvent-borne Degreaser, #6311 / #6321 Transtar Waterborne degreaser, #1394 Lint-free Towels
- Sandpaper − various grits Sanding blocks Palm Sander Scuff pads Transtar Scuff & Prep Paste, #6338
- Transtar Guide Coat, #9183 Tack rags Transtar Corrosion Protection Primer Transtar Primer Surfacer

^{*} Always refer to Transtar Technical Data Sheet (TDS) for specific product application, suitable substrates & other product information.