



Transtar does not recommend applying our urethane or iso-free primers on the bare fiberglass substrates of Corvettes made before 1984.

Problems can arise such as blistering and peeling. Instead, we recommend using 6541-G Kwik Fill Polyester Primer on the bare substrate, then if needed use a Transtar urethane or iso-free primer to do any surfacing and sealing.

